

Trionic 517

TF or Freon 113) 99% 76-13-1 20 1 ASTM F739 1 - 1,2 Dichloroethylene 98% 156-60-5 2 0 ASTM F739 2 - 1,3 Ethoxy propionate (Ethyl 3-ethoxypropionate) 99% 763-69-9 480 6 ASTM F739 NT NA 2-Butoxyethanol (Butyl Cellusolve) 99% 111-76-2 53 2 ASTM F739 NT NA 2-Butoxyethylacetate (Butyl cellosolve acetate) 85% 112-07-2 35 2 ASTM F739 NT NA 2-Ethoxyethanol (Cellosolve) 99% 110-80-5 27 1 ASTM F739 NT NA 2-Ethoxyethanol (Cellosolve) 99% 110-80-5 27 1 ASTM F739 NT NA 2-Ethoxyethanol (Cellosolve) 99% 110-80-5 27 1 ASTM F739 NT NA 2-Ethoxyethanol (Cellosolve) 99% 109-86-4 400 2 ASTM F739 NT NA 2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98% 109-86-4 400 2 ASTM F739 NT NA 2-Propanol (Isopropanol) 99% 67-63-0 29 1 <	Chemical Product	CAS #	BTT (minutes)	Permeation level	Standard	Degradatio level	Rating
1.1.2-Trichlorosthane (Frem TF or Frem 113) 99%76-13-1201ASTM F73911.2 Dichloroethylene 98%156-60-520ASTM F7392-3.3 Ethoxy propionate (Ethyl 3-ethoxy propionate) 99%763-69-94806ASTM F739NTNA2-Butoxy ethylacetate (Ethyl 99%111-76-2532ASTM F739NTNA2-Butoxy ethylacetate (Butyl cellosolve acetate) 85%112-07-2352ASTM F739NTNA2-Ethoxy ethylacetate (Cellosolve Acetate) 99%110-80-5271ASTM F739NTNA2-Ethoxy ethanol (Cellosolve) 99%110-80-5271ASTM F739NTNA2-Ethoxy ethanol (Cellosolve) 99%109-86-4402ASTM F739NTNA2-Methoxy ethanol (Methyl cellosolve) 99%109-86-4402ASTM F739NTNA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:20034+4.4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in To Ioluene mixture101-77-9191ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in To Ioluene mixture101-77-9191ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in To Ioluene mixture101-77-9151ASTM F739A+4.4'-Methylenedianiline (MDA) 15% in To Ioluene mixture101-77-9 </td <td></td> <td></td> <td>7</td> <td>0</td> <td>ASTM F739</td> <td>NT</td> <td>NA</td>			7	0	ASTM F739	NT	NA
TF or Freon 113) 99%76-13-1201ASIM F7391-1.2 Dichloroethylene 98%156-60-520ASTM F7392-1.3 Ethoxy propionate (Ethyl 3-ethoxy propionate) 99%763-69-94806ASTM F739NTNA2-Butoxyethanol (Butyl Cellusolve) 99%111-76-2532ASTM F739NTNA2-Butoxyethylacetate (Butyl cellosolve) 99%112-07-2352ASTM F739NTNA2-Ethoxyethylacetate (Cellosolve) Acetate) 99%110-80-5271ASTM F739NTNA2-Ethoxyethylacetate (Cellosolve) acetate) 99%109-86-44002ASTM F739NTNA2-Methoxyethanol (Methyl cellosolve) 99%109-86-44002ASTM F739NTNA2-Methoxyethanol (Methyl cellosolve) 99%109-86-44002ASTM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve) 99%101-77-9191EN 374-3:20034+4.4 - diamino diphenylsulfone 97% and 15% Methanol mixture101-77-9151ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151EN 374-3:20034+4.4'-Methylenedianiline	1,1,1,2,2,3,4,5,5,5-Decafluoropentan 97%	ʻ138495-42-8	13	1	ASTM F739	NT	NA
1.3 Ethoxy propionate (Ethyl 3-ethoxypropionate) 99%763-69-94806ASTM F739NTNA2-Butoxyethylacetate (Butyl cellosolve acetate) 85%112-07-2352ASTM F739NTNA2-Ethoxyethylacetate (Butyl cellosolve acetate) 85%112-07-2352ASTM F739NTNA2-Ethoxyethylacetate (Cellosolve) 99%110-80-5271ASTM F739NTNA2-Ethoxyethyl acetate (Cellosolve) 	1,1,2-Trichlorotrifluoroethane (Freon TF or Freon 113) 99%	76-13-1	20	1	ASTM F739	1	-
3-ethoxyprojonate)99%703-80-94406A SIM P739NTNA2-Butoxyethanol (Butyl Cellusolve) 99%111-76-2532A STM F739NTNA2-Butoxyethylacetate (Butyl cellosolve acetate) 85%112-07-2352A STM F739NTNA2-Ethoxyethylacetate (Cellosolve) 99%110-80-5271A STM F739NTNA2-Ethoxyethanol (Cellosolve) 99%110-80-5271A STM F739NTNA2-Ethoxyethanol (Methyl cellosolve) 99%109-86-4402A STM F739NTNA2-Methoxyethanol Acetate (Cellosolve) 	1,2 Dichloroethylene 98%	156-60-5	2	0	ASTM F739	2	-
99%111-10-2332ASIM 17.33NTMA2-Butoxyethylacetate (Butyl cellosolve acetate) 85%112-07-2352ASTM F739NTNA2-Ethoxyethanol (Cellosolve) 99%110-80-5271ASTM F739NTNA2-Ethoxyethyl acetate (Cellosolve Acetate) 99%111-15-9141ASTM F739A+2-Methoxyethanol (Methyl Cellosolve) 99%109-86-4402ASTM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%110-49-6271ASTM F739NTNA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:20034+4,4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9191ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NANAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%67-64-160ASTM F7394++Aluminum Etch mixtureNA552ASTM F739NTNAAluminum Oxide mixtureNA552ASTM F739NT <td>3-ethoxypropionate) 99%</td> <td>763-69-9</td> <td>480</td> <td>6</td> <td>ASTM F739</td> <td>NT</td> <td>NA</td>	3-ethoxypropionate) 99%	763-69-9	480	6	ASTM F739	NT	NA
Cellosolve acetate) 85%.II2-07-2332ASTM F739N1NA2-Ethoxyethanol (Cellosolve) 99%110-80-5271ASTM F739NTNA2-Ethoxyethyl acetate (Cellosolve)111-15-9141ASTM F739442-Methoxyethanol (Methyl Cellosolve) 99%109-86-4402ASTM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%100-86-4402ASTM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%10-49-6271ASTM F739NTNA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:2003444,4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4,4 - Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4,4 - Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNA4,4 - Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9151ASTM F739NTNA4,4 - Methylenedianiline (MDA) 15% in Toluene mixture64-19-7NTNT4NAAcetic acid 10%64-19-7NTNT4AAcetic acid 99%67-64-160ASTM F7394 ++ Aluminum Etch mixtureNA552ASTM F739NTNAAluminum Milueride 40%		111-76-2	53	2	ASTM F739	NT	NA
2-Ethoxyethyl acetate (Cellosolve Acetate) 99% 111-15-9 14 1 ASTM F739 4 + 2-Methoxyethanol (Methyl Cellosolve) 99% 109-86-4 40 2 ASTM F739 NT NA 2-Methoxyethanol Acetate (Methyl Cellosolve acetate) 98% 110-49-6 27 1 ASTM F739 NT NA 2-Propanol (Isopropanol) 99% 67-63-0 29 1 EN 374-3:2003 4 + 4,4 - diamino diphenylsulfone 97% 80-008-0 480 6 ASTM F739 NT NA 4,4 - Methylenedianiline (MDA) 15% and 15% Methanol mixture 101-77-9 19 1 ASTM F739 NT NA 4,4'-Methylenedianiline (MDA) 15% in Toluene mixture 101-77-9 15 1 ASTM F739 NT NA Acetic acid 10% 64-19-7 NT NT 4 NA Acetic acid 50% 64-19-7 NT NT 4 NA Acetic acid 99% 67-64-1 6 0 ASTM F739 4 ++ Acetone 99% 67-64-1 6 0 ASTM F739 4 ++ <t< td=""><td>2-Butoxyethylacetate (Butyl cellosolve acetate) 85%</td><td>112-07-2</td><td>35</td><td>2</td><td>ASTM F739</td><td>NT</td><td>NA</td></t<>	2-Butoxyethylacetate (Butyl cellosolve acetate) 85%	112-07-2	35	2	ASTM F739	NT	NA
Acetate) 99%111-13-9141ASTM F739442-Methoxyethanol (Methyl Cellosolve) 99%109-86-4402ASTM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%110-49-6271ASTM F739NTNA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:20034+4,4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4,4 - Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%67-64-160ASTM F7394+Acetic acid 99%67-64-160ASTM F7394+Acetic acid 99%67-64-160ASTM F7394+Aluminum Etch mixtureNA9605ASTM F739NTNAAluminum Cyide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNA	2-Ethoxyethanol (Cellosolve) 99%	110-80-5	27	1	ASTM F739	NT	NA
Cellosolve) 99%ID9-36-4402ASIM F739NTNA2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%110-49-6271ASTM F739NTNA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:20034+4.4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4.4 - Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F739AT++Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNA	2-Ethoxyethyl acetate (Cellosolve Acetate) 99%	111-15-9	14	1	ASTM F739	4	+
cellosolve acetate) 98%110-49-6271ASTM F739N1NA2-Propanol (Isopropanol) 99%67-63-0291EN 374-3:20034+4,4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F739NTNAAluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNA		109-86-4	40	2	ASTM F739	NT	NA
4,4 - diamino diphenylsulfone 97%80-008-04806ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%64-19-7291EN 374-3:20034+Acetone 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F739NTNAAluminum Fluoride 40%12125-01-84806ASTM F739NTNAAmmonium Fluoride 79%12125-01-84806ASTM F739NTNA	2-Methoxyethanol Acetate (Methyl cellosolve acetate) 98%	110-49-6	27	1	ASTM F739	NT	NA
4.4'-Methylenedianiline (MDA) 15% and 15% Methanol mixture101-77-9191ASTM F739NTNA4.4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%64-19-7291EN 374-3:20034+Acetone 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F7394++Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 79%12125-01-84806ASTM F739NTNA	2-Propanol (Isopropanol) 99%	67-63-0	29	1	EN 374-3:2003	4	+
and 15% Methanol mixture101-77-9191ASTM F739N1NA4,4'-Methylenedianiline (MDA) 15% in Toluene mixture101-77-9151ASTM F739NTNAAcetic acid 10%64-19-7NTNTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%64-19-7291EN 374-3:20034+Acetone 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F7394++Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNA	4,4 - diamino diphenylsulfone 97%	80-008-0	480	6	ASTM F739	NT	NA
In Toluene mixtureInt=77-9ISIASTM F739NTNAAcetic acid 10%64-19-7NTNT4NAAcetic acid 50%64-19-7NTNT4NAAcetic acid 99%64-19-7291EN 374-3:20034+Acetone 99%67-64-160ASTM F7394=Aluminum Etch mixtureNA9605ASTM F7394++Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNA	4,4'-Methylenedianiline (MDA) 15% and 15% Methanol mixture	101-77-9	19	1	ASTM F739	NT	NA
Acetic acid 50% 64-19-7 NT NT NT 4 NA Acetic acid 99% 64-19-7 29 1 EN 374-3:2003 4 + Acetone 99% 67-64-1 6 0 ASTM F739 4 = Aluminum Etch mixture NA 960 5 ASTM F739 4 ++ Aluminum Oxide mixture NA 55 2 ASTM F739 NT NA Ammonium Fluoride 40% 12125-01-8 480 6 ASTM F739 NT NA Ammonium Fluoride 79% 12125-01-8 480 6 ASTM F739 NT NA	4,4'-Methylenedianiline (MDA) 15% in Toluene mixture	101-77-9	15	1	ASTM F739	NT	NA
Acetic acid 99% 64-19-7 29 1 EN 374-3:2003 4 + Acetone 99% 67-64-1 6 0 ASTM F739 4 = Aluminum Etch mixture NA 960 5 ASTM F739 4 ++ Aluminum Oxide mixture NA 55 2 ASTM F739 NT NA Ammonium Fluoride 40% 12125-01-8 480 6 ASTM F739 NT NA Ammonium Fluoride 79% 12125-01-8 480 6 ASTM F739 NT NA	Acetic acid 10%	64-19-7	NT	NT		4	NA
Acetone 99% 67-64-1 6 0 ASTM F739 4 = Aluminum Etch mixture NA 960 5 ASTM F739 4 ++ Aluminum Oxide mixture NA 55 2 ASTM F739 NT NA Ammonium Fluoride 40% 12125-01-8 480 6 ASTM F739 NT NA Ammonium Fluoride 79% 12125-01-8 480 6 ASTM F739 NT NA	Acetic acid 50%	64-19-7	NT	NT		4	NA
Aluminum Etch mixtureNA9605ASTM F7394++Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNAAmmonium Fluoride 79%12125-01-84806ASTM F739NTNA	Acetic acid 99%	64-19-7	29	1	EN 374-3:2003	4	+
Aluminum Oxide mixtureNA552ASTM F739NTNAAmmonium Fluoride 40%12125-01-84806ASTM F739NTNAAmmonium Fluoride 79%12125-01-84806ASTM F739NTNA	Acetone 99%	67-64-1	6	0	ASTM F739	4	=
Ammonium Fluoride 40% 12125-01-8 480 6 ASTM F739 NT NA Ammonium Fluoride 79% 12125-01-8 480 6 ASTM F739 NT NA	Aluminum Etch mixture	NA	960	5	ASTM F739	4	++
Ammonium Fluoride 79% 12125-01-8 480 6 ASTM F739 NT NA	Aluminum Oxide mixture	NA	55	2	ASTM F739	NT	NA
	Ammonium Fluoride 40%	12125-01-8	480	6	ASTM F739	NT	NA
Ammonium hydroxide solution 29% 1336-21-6 19 1 EN 374-3:2003 4 +	Ammonium Fluoride 79%	12125-01-8	480	6	ASTM F739	NT	NA
	Ammonium hydroxide solution 29%	1336-21-6	19	1	EN 374-3:2003	4	+

*not normalized result

Overall Chemical Protection Rating

Protection rating is determined by taking into account the effects of both permeation and degradation in an attempt to provide users with an overall protection guideline when using our glove products against specific chemicals.

Used for high chemical exposure or chemical immersion, limited to BTT based on a working day.

Used for repeated chemical contact, limited to total chemical exposure i.e. : accumulative BTT based on a working day.
Splash protection only, on chemical exposure the gloves should be discarded and new gloves worn as soon as possible.

Not recommended, these gloves are deemed unsuitable for work with this chemical.

NT : Not tested

NA : Not applicable because not fully tested (only degradation OR permeation results)





Trionic 517

Chemical Product	CAS #	BTT (minutes)	Permeation level	Standard	Degradatio level	Rating
Baker PRS-1000 mixture	NA	20	1	ASTM F739	NT	NA
Baker PRS-2000 mixture	NA	130	4	ASTM F739	NT	NA
Baker PRS-3000 mixture	NA	480	6	ASTM F739	NT	NA
Benzene 99%	71-43-2	4	0	ASTM F739	1	-
Buffered Oxide Etch mixture	NA	480	6	ASTM F739	4	++
Butyl Acetate 99%	123-86-4	5	0	EN 374-3:2003	4	=
Chromic Acid 50%	7738-94-5	60	2	ASTM F739	NT	NA
Cyclohexanone 99%	108-94-1	23	1	ASTM F739	1	-
Cyclopentanone 99%	120-92-3	11	1	ASTM F739	NT	NA
Dichloromethane (Methylene Chloride) 99%	75-09-2	4	0	ASTM F739	NT	NA
Dichromate cleaning solution mixture	NA	480	6	ASTM F739	4	++
Diethylamine 98%	109-89-7	4	0	ASTM F739	NT	NA
Diglycidal ether of bisphenol 100%	25068-38-6	480	6	ASTM F739	NT	NA
Dimethylamine 35%	124-40-3	53	2	ASTM F739	NT	NA
Dimethylformamide 99%	68-12-2	8	0	ASTM F739	NT	NA
Dimethylsulfoxide 99%	67-68-5	181	4	ASTM F739	4	++
Epichlorohydrin 99%	106-89-8	4	0	ASTM F739	NT	NA
Ethanol 95%	64-17-5	21	1	ASTM F739	NT	NA
Ethyl lactate 95%	97-64-3	29	1	ASTM F739	NT	NA
Ethylene glycol 99%	107-21-1	480	6	ASTM F739	4	++
Hexamethyldisilazane (HMDS) 98%	999-97-3	18	1	ASTM F739	1	-
Hydrochloric acid 10%	7647-01-0	480	6	EN 374-3:2003	4	++
Hydrochloric acid 35%	7647-01-0	NT	NT		4	NA
Hydrochloric acid 37%	7647-01-0	454	5	ASTM F739	4	++
Hydrofluoric Acid 10%	7664-39-3	480	6	EN 374-3:2003	4	++
Hydrofluoric Acid 49%	7664-39-3	480	6	EN 374-3:2003	NT	NA

*not normalized result

Overall Chemical Protection Rating

Protection rating is determined by taking into account the effects of both permeation and degradation in an attempt to provide users with an overall protection guideline when using our glove products against specific chemicals.

Used for high chemical exposure or chemical immersion, limited to BTT based on a working day.

Used for repeated chemical contact, limited to total chemical exposure i.e. : accumulative BTT based on a working day.
Splash protection only, on chemical exposure the gloves should be discarded and new gloves worn as soon as possible.

Not recommended, these gloves are deemed unsuitable for work with this chemical.

NT : Not tested

NA : Not applicable because not fully tested (only degradation OR permeation results)





Trionic 517

Chemical Product	CAS #	BTT (minutes)	Permeation level	Standard	Degradatio level	Rating
Hydrogen peroxide 30%	7722-84-1	960	5	ASTM F739	4	++
Hydrotreated Light Naphthenic Distillate mixture	64742-53-6	161	4	ASTM F739	2	+
Kerosene mixture	8008-20-6	26	1	ASTM F739	1	-
KOH Etch mixture	NA	278	5	ASTM F739	4	++
KTI Pad Etch mixture	NA	480	6	ASTM F739	NT	NA
KTI Silicon Etch mixture	NA	480	6	ASTM F739	NT	NA
Methanesulfonic Acid 99%	75-75-2	NT	NT		4	NA
Methanol 85%	67-56-1	19	1	ASTM F739	4	+
Methanol 99%	67-56-1	NT	NT		4	NA
Methyl Amyl Ketone 98%	110-43-0	8	0	ASTM F739	1	-
Methyl Ethyl Ketone (2-Butanone) 99%	78-93-3	4	0	ASTM F739	3	=
Methyl-3-methoxypropionate 100%	3852-09-3	11	1	ASTM F739	3	=
n-hexane 95%	110-54-3	3	0	ASTM F739	1	-
N-methyl-2-Pyrrolidone 99%	872-50-4	33	2	EN 374-3:2003	4	+
N-N dimethyl acetamide 99%	127-19-5	47	2	ASTM F739	NT	NA
Naphtha VM&P mixture	8032-32-4	2	0	ASTM F739	1	-
Nitric acid 10%	7697-37-2	840	5	ASTM F739	4	++
Nitric acid 20%	7697-37-2	480	6	ASTM F739	4	++
Nitric acid 40%	7697-37-2	480	6	ASTM F739	4	++
Nitric acid 50%	7697-37-2	NT	NT		4	NA
Nitric acid 68%	7697-37-2	299	5	EN 374-3:2003	4	++
Nitric acid 70%	7697-37-2	307	5	ASTM F739	4	++
Nitric acid 90%	7697-37-2	7	0	ASTM F739	NT	NA
Nitride Etch mixture	NA	NT	NT		4	NA
Nitrohydrochloric acid (Aqua Regia) mixture	8007-56-5	480	6	ASTM F739	NT	NA
Phenol 85%	108-95-2	102	3	ASTM F739	4	++
					*ne	ot normalized result

*not normalized result

Overall Chemical Protection Rating

Protection rating is determined by taking into account the effects of both permeation and degradation in an attempt to provide users with an overall protection guideline when using our glove products against specific chemicals.

Used for **high chemical exposure** or chemical immersion, limited to BTT based on a working day.

Used for repeated chemical contact, limited to total chemical exposure i.e. : accumulative BTT based on a working day.
Splash protection only, on chemical exposure the gloves should be discarded and new gloves worn as soon as possible.

Not recommended, these gloves are deemed unsuitable for work with this chemical.

NT : Not tested

NA : Not applicable because not fully tested (only degradation OR permeation results)





Trionic 517

Chemical Product	CAS #	BTT (minutes)	Permeation level	Standard	Degradatio level	Rating
Phosphoric acid 75%	7664-38-2	480	6	ASTM F739	4	++
Phosphoric acid 85%	7664-38-2	480	6	ASTM F739	4	++
Phosphorus Oxychloride 99%	10025-87-3	15	1	ASTM F739	NT	NA
Piranha Etch mixture	NA	243	5	ASTM F739	1	-
Polyethylene glycol octylphenyl ether 100%	9002-93-1	480	6	ASTM F739	NT	NA
Potassium Hydroxide 50%	1310-58-3	480	6	ASTM F739	4	++
Potassium Hydroxide Etch mixture	NA	24	1	ASTM F739	NT	NA
Propylene Glycol 99%	57-55-6	480	6	ASTM F739	4	++
Propylene Glycol Methyl Ethyl Acetate (PGMEA) 99%	108-65-6	47	2	ASTM F739	3	+
Propylene Glycol Monomethyl Ether 99%	107-98-2	26	1	ASTM F739	4	+
Silicon Tetrachloride 100%	10026-04-7	15	1	ASTM F739	NT	NA
Slope Etch mixture	NA	260	5	ASTM F739	4	++
Sodium hydroxide 20%	1310-73-2	780	5	ASTM F739	4	++
Sodium hydroxide 40%	1310-73-2	780	5	ASTM F739	4	++
Sodium hydroxide 50%	1310-73-2	780	5	ASTM F739	4	++
Sulfuric acid 10%	7664-93-9	900	5	ASTM F739	4	++
Sulfuric acid 96%	7664-93-9	41	2	EN 374-3:2003	1	-
Tetrachloroethylene (Perchloroethylene) 99%	127-18-4	3	0	EN 374-3:2003	1	-
Tetraethyl Orthosilicate 100%	78-10-4	25	1	ASTM F739	1	-
Tetramethyl Ammonium Hydroxide 25%	75-59-2	480	6	ASTM F739	4	++
Thionylchloride 99%	7719-09-7	15	1	ASTM F739	NT	NA
Toluene 49% Methyl Isobutyl Ketone 34.5% Methyl Ethyl Ketone 16.5% mixture	NA	1	0	EN 374-3:2003	NT	NA
Toluene Diisocyanate (TDI) 80%	584-84-9	27	1	ASTM F739	NT	NA
Trichloroethylene 99%	79-01-6	NT	NT		1	NA
Trimethylphosphite 97%	121-45-9	10	0	ASTM F739	NT	NA normalized result

*not normalized result

Overall Chemical Protection Rating

Protection rating is determined by taking into account the effects of both permeation and degradation in an attempt to provide users with an overall protection guideline when using our glove products against specific chemicals.

Used for **high chemical exposure** or chemical immersion, limited to BTT based on a working day.

Used for repeated chemical contact, limited to total chemical exposure i.e. : accumulative BTT based on a working day.
Splash protection only, on chemical exposure the gloves should be discarded and new gloves worn as soon as possible.

Not recommended, these gloves are deemed unsuitable for work with this chemical.

NT : Not tested

NA : Not applicable because not fully tested (only degradation OR permeation results)



Trionic 517

Chemical Product	CAS #	BTT (minutes)	Permeation level	Standard	Degradatio level	Rating
Unleaded gasoline mixture	8006-61-9	4	0	ASTM F739	1	-
Xylene 99%	1330-20-7	3	0	EN 374-3:2003	1	-

*not normalized result

Overall Chemical Protection Rating

Protection rating is determined by taking into account the effects of both permeation and degradation in an attempt to provide users with an overall protection guideline when using our glove products against specific chemicals.

Used for **high chemical exposure** or chemical immersion, limited to BTT based on a working day.

Used for repeated chemical contact, limited to total chemical exposure i.e. : accumulative BTT based on a working day.
Splash protection only, on chemical exposure the gloves should be discarded and new gloves worn as soon as possible.

Not recommended, these gloves are deemed unsuitable for work with this chemical.

NT : Not tested

NA : Not applicable because not fully tested (only degradation OR permeation results)

